

QBUS+NOVUS

Disassembly and repair instructions

1-leg desk



Repair & Disassembly

Spare parts
Disassembly
Parts and Materials

Page 2
Page 3
Page 4


Save this document for future use.
This document provides information that may be subject to change without prior notice.

QBUS+NOVUS

1-leg desk

Disassembly and repair instructions

Spare parts




No.	Reference ID	AJ article	Description	Benämning
1	G6	62608	Handset for table QBUS/NOVUS, 1-leg frame	Handkontroll till bord QBUS/NOVUS, 1-ben stativ
2	G7	62607	Power adapter for 1-leg frame	Nätadapter till 1-ben stativ
3	G5	62601	Adjustable feet for 1-leg frame	Justerbar fot till 1-ben stativ

QBUS+NOVUS

1-leg desk

Disassembly and repair instructions

Disassembly



SV: För detaljerad vägledning, se monteringsanvisningarna.

EN: For detailed guidance, please refer to the assembly instructions.

LV: Lai iegūtu detalizētas instrukcijas, skatiet montāžas rokasgrāmatu.

CS: Podrobné pokyny naleznete v návodu k montáži.

NL: Raadpleeg de montagehandleiding voor gedetailleerde instructies.

DA: For detaljeret vejledning henvises der til samlevejledningen.

PL: Szczegółowe informacje znajdują się w instrukcji montażu.

DE: Detaillierte Anleitungen finden Sie in der Montageanleitung.

SK: Podrobné pokyny nájdete v návode na montáž.

ET: Üksikasjalike juhiste saamiseks vaadake kokkupanekujuhendit.

SL: Za podrobna navodila glejte navodila za sestavljanje.

FI: Tarkempia ohjeita saat kokoamisohjeista.

NO: For detaljert veiledning, vennligst se monteringsanvisningen.

LT: Išsamią informaciją rasite surinkimo instrukcijoje.

QBUS+NOVUS

1-leg desk

Disassembly and repair instructions

Parts and materials



Part no.	Description	Material
1	Handset for table QBUS/NOVUS, 1-leg frame	Electronics*
2	Power adapter for 1-leg frame	Electronics*
3	Adjustable feet for 1-leg frame	Plastic
4	Table top	Melamine faced chipboard (Wood)
5	Side frame	Metal
6	Leg	Electronics*
7	Leg frame	Metal
8	Leg frame	Metal
9	Fixing plate	Metal



* The crossed-out wheeled bin symbol indicates that the item must not be disposed of with normal, unsorted general waste. The item must be sent to separate collection facilities for recovery and recycling in accordance with local waste disposal regulations. By separating electronic equipment and batteries from general waste, you help reduce the volume of waste sent to incineration or landfill and minimise any potential negative effects on the environment and human health.